

CARE & MAINTENANCE

Autex Interior Acoustics and Quietspace® products are extremely durable and require little attention to maintain their good looks. Light vacuuming on a regular basis will prevent dust build up and most marks can be cleaned with a mild detergent solution followed by rinsing and blotting. Stains should be dealt with according to the chart below. Before carrying out a proposed cleaning method, apply to a concealed section to ensure it will not affect the adhesive or product. Avoid severe abrasion. Spot clean only. Vacuum to restore pile, but do not use a stiff brush.

NB: We do not recommend using solvent-based solutions on Autex Interior Acoustics and Quietspace® products.

STAIN	TREATMENT GUIDE
Blood	A C
Burn/Scorch Mark	J
Chewing Gum	B C D H
Chocolate	B C D
Cooking Oils	B C D
Crayon/Colour Markers	B C D
Drinks (cola, tea, juices, beer etc.)	A C
Dust/Dirt	Vacuum, then I or C
Excrement	B C
Grass	C
Grease	B C D
Ink (ballpoint)	D
Ink (fountain)	A C
Lipstick	B C D
Mildew	C
Milk	A
Mud	B C
Nail Polish	A F
Oil	B C D
Paint (water based)	A C E
Paint (oil based)	A C D G
Sauces	B C D
Shoe Polish	B C D
Urine	A C
Vomit	A C D
Wine	A Add Salt C

KEY

- A** Mop up excess as soon as possible with a sponge or cloth.
- B** Remove surplus with a knife edge or appropriate instrument.
- C** Sponge with a solution of carpet shampoo working from well outside the stain in a circular motion towards the centre (this avoids spreading the stain). Sponge afterwards with clean warm water and mop excess moisture with a clean dry cloth or sponge. Allow to dry then brush gently with a soft brush. If any stain remains, sponge with a solution of one part household bleach to six parts clear water. Thoroughly rinse after treatment.
- D** Lightly sponge with household dry cleaning fluid and blot. Apply sparingly, as the substance may have an adverse effect on the adhesive.
- E** Lubricate the stain with glycerine or petroleum jelly.
- F** Apply nail polish remover. The nail polish remover should not include lanolin or be of a greasy nature.
- G** Sponge with turpentine (or substitute).
- H** Freeze with ice cubes and scrape away while cold.
- I** Clean with regular extractive carpet cleaner (if possible).
- J** Use circular cutter and remove damaged portion. Re-glue new piece into place.



Australia Freephone
1800 24 36 37
Website
www.chemdry.com.au



NZ Freephone
0800 222 379
Website
www.enviro.co.nz

SPECIALIST FINISHES

Autex recommends that you contact professional cleaning experts should you require further assistance with the cleaning and maintenance of Autex Interior Acoustic products. Enviro Clean & Restoration have trialled their cleaning regime with the Interior Acoustics product range and we recommend their service for our New Zealand customers. For Australia, ChemDry® have trialled their cleaning regime with the Interior Acoustics product range and we recommend their service. For enquiries in the U.K., US or South East Asia contact your local Account Manager.

Autex Industries has no affiliation with Enviro Clean & Restoration or ChemDry and are not responsible for any outcome of the service. The above listed treatments are intended as general guidance only. Results may vary depending on variables beyond the control of Autex Industries. Autex Industries accepts no responsibility or liability for any loss or damage which may arise from implementation of the above listed treatments.

Autex Industries Ltd

702-718 Rosebank Rd
Private Bag 19988
Avondale 1746, Auckland
New Zealand
Freephone **0800 428 839**
Phone **+64 9 828 9179**
Fax **+64 9 828 5810**
www.autex.co.nz

Autex Australia Pty Ltd

166 Barnfield Road
PO Box 5099
West Heidelberg, Melbourne
VIC 3081, Australia
Freephone **1800 678 160**
Phone **+61 3 9457 6700**
Fax **+61 3 9457 1020**
www.autex.com.au

Autex Acoustics Ltd

Unit 1 Alchemy Industrial Est.
Platinum Court, Alchemy Way
Liverpool, L33 7XN
United Kingdom
Phone **+44 151 294 3236**
Fax **+44 151 546 0863**
www.autexacoustics.co.uk

Autex Acoustics LLC

California
USA
Phone **+1 805 407 9256**
Fax **+1 805 457 8932**
www.autexacoustics.com

